

Safety Warnings

- To reduce the risk of electric shock, do not expose this appliance to rain or moisture. Potentially dangerous high voltages are present inside the enclosure. Do not open the main housing. Refer servicing to qualified personnel only.
- For your safety, never handle the unit with wet hands, as this could cause electric shock.
- Never attempt to repair the unit by yourself. This should be done only by a qualified service technician.

FCC Compliance

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Limited 90-Day Warranty

EXCALIBUR ELECTRONICS, INC., warrants to the original consumer that its products are free from any electrical or mechanical defects for a period of 90 DAYS from the date of purchase. If any such defect is discovered within the warranty period, EXCALIBUR ELECTRONICS, INC., will repair or replace the unit free of charge upon receipt of the unit, shipped postage prepaid and insured to the factory address below. The warranty covers normal consumer use and does not cover damage that occurs in shipment or failure that results from alterations, accident, misuse, abuse, neglect, wear and tear, inadequate maintenance, commercial use, or unreasonable use of the unit. Removal of the top panel voids all warranties. This warranty does not cover cost of repairs made or attempted outside of the factory. Any applicable implied warranties, including warranties of merchantability and fitness, are hereby limited to 90 DAYS from the date of purchase. Consequential or incidental damages resulting from a breach of any applicable express or implied warranties are hereby excluded. Some states do not allow limitations on the duration of implied warranties and do not allow exclusion of incidental or consequential damages, so the above limitations and exclusions in these instances may not apply. The only authorized service center in the United States is:

Excalibur Electronics, Inc.
13755 SW 119th Ave.
Miami, FL 33186 U.S.A.

Ship the unit carefully packed, preferably in the original carton, and send it prepaid, and adequately insured. Include a letter detailing the complaint, along with your daytime telephone number, inside the shipping carton. If your warranty has expired and you want an estimated fee for service, write to the above address, specifying the model and the problem.

PLEASE DO NOT SEND YOUR UNIT WITHOUT RECEIVING AN ESTIMATE FOR SERVICING.
WE CANNOT STORE YOUR UNIT!



Excalibur Electronics, Inc.
13755 SW 119th Avenue • Miami, FL 33186
Tel: 305.477.8080 • Fax: 305.477.9516 • www.ExcaliburElectronics.com

SOUNDMASTER is a trademark of Excalibur Electronics, Inc.
iPod is a trademark of Apple, Inc., registered in the U.S. and other countries.
Actual product may differ slightly from photograph.



RETRACTABLE HEADPHONES
EAR BUDS FOR iPod®

SOUNDMASTER™ RETRACTABLE HEADPHONES
OPERATION MANUAL

Introduction

Congratulations on your purchase of the **SOUNDMASTER™ Retractable Headphones** from Excalibur Electronics, Inc. You will enjoy hours of great music with this innovative headphone set. The retractable mechanism makes them easy to carry around without long, annoying cords. They are compatible with iPod, MP3 players, MiniDISC players and portable media players. Your Retractable Headphones are easy to use, but be sure to use them safely. Before starting, please read this manual thoroughly, especially noting safety and care. Keep this manual for reference. This package includes one pair of SOUNDMASTER™ Retractable Headphones and User's Guide.



Using your SOUNDMASTER™ Retractable Headphones

Plug your retractable headphones into the headphone socket of your audio device. Insert the earpieces into your ears. Follow the instructions of your audio device to adjust the volume or sound.

*Enjoy crisp, high-quality stereo sound plus innovative design with the **SOUNDMASTER™ Retractable Headphones**. Simply pull the corded headphones and stereo mini-plug from the spool to extend its length for a custom, tangle-free fit. You can also attach the spool to your shirt, pocket or purse via the built-in utility clip. The headphones are compatible with most audio devices including MP3 players, CD/DVD players, desktop computers, laptops, gaming devices and more.*



Special Care & Handling

- Avoid rough handling such as bumping or dropping.
- Avoid extreme temperatures. For best results, use between 39° F and 120° F (4° C and 38° C).
- Clean using only a slightly damp cloth. Do not use cleaners with harsh chemical agents or detergents.
- To avoid damaging the unit, never place it near radiators, in front of heating vents, in direct sunlight, or near water.



NOTE: DO NOT EXPOSE YOUR **SOUNDMASTER™**
RETRACTABLE HEADPHONES TO RAIN OR MOISTURE.

